
INSTALLATION INSTRUCTIONS FOR UA PRODUCTS :

UA0059 IS	Pierre	UA0304 EL	Park Place
UA0277 EL	Cottage	UA0309 EL	Gothic
UA0278-W EL	Sutton Place	UA0310 EL	Griffin
UA0279 EL	Chelsea Wallmount	UA0312-W EL	Prince Wallmount
UA0282-W EL	Madison Wallmount	UA0316 EL	Princeton Wallmount
UA0284 EL	Fifth Avenue	UA0317 EL	Evergreen
UA0286 EL	Riverside [Small Backplate]	UA0318-W EL	St. Patrick's Wallmount
UA0289-W EL	Lafayette Wallmount	UA0319-W EL	Cardinal Wallmount
UA0294-W EL	Astor Place	UA0320-W EL	Cambridge Wallmount
UA0296 EL	Train Station	UA0321 EL	Columbia
UA0297-6 EL	Franklin Lantern	UA0324 EL	Bryant Park
UA0299 EL	Prospect Bracket	UA0325-W EL	Roxy
UA0300-W EL	Large Mission Wallmount	UA0327-W EL	University Wallmount
UA0302-W EL	Yorkville Wallmount	UA0332-W EL	Park Slope

INSTRUCTIONS:

1. Mark, drill, and prepare appropriate anchors for your particular wall construction.
2. Attach end of lanyard to wall anchor using screw provided.
3. Gently lower fixture so weight is supported by lanyard.
4. Connect white wire to white supply wire.
5. Connect black wire to black supply wire.
6. Connect ground wire (green) to junction box.
7. Apply bead of silicone caulk to back of fixture bottom (For Wet or Damp location only)
8. Lift and mount fixture to wall using screws provided.
9. Locate the glass panels (each fixture is numbered and each panel of glass is numbered in order to locate the glass in the correct opening). Adjust each glass panel and secure gently with the interior tabs. Do not over tighten.
10. Secure all glass with a thin bead of silicone.

WARNING:

**RISK OF FIRE AND ELECTRICAL SHOCK IF IMPROPERLY INSTALLED.
MUST BE INSTALLED BY A LICENSED ELECTRICIAN ACCORDING TO
INSTRUCTIONS PROVIDED.**

CAUTION:

TURN OFF POWER AT MAIN ELECTRICAL BOX BEFORE INSTALLATION.