


Single Prismatic Standard Installations

WARNING: RISK OF FIRE AND ELECTRICAL SHOCK. THIS PRODUCT TO BE INSTALLED BY A QUALIFIED ELECTRICIAN.
CAUTION: TURN OFF POWER AT MAIN ELECTRICAL BOX BEFORE INSTALLATION.

1. Mount universal bracket bar to junction box.
2. Connect white wire to white [neutral] supply wire.
3. Connect black wire to black [hot] wire.
4. Connect ground wire to junction box.

5. Mount hang-straight to universal bracket.



6. Hook 3 support arms through holes in upper housing. Locate shade in housing.



7. Open lens frame. Locate support arms in frame. Secure with 3 screws. Simultaneously locate shade in frame.

8. Close lens frame, rotate thread pin to a vertical position and secure in place with screw provided.

